



Tier 1 Using the Blu-Ray Player

1. Push the power button on the control panel "On." This should turn on the projector and lower the projection screen. If the screen does not lower, find the switch on the wall that controls the screen and lower it manually.



2. Turn on the Blu-ray Player using the button on the front of the player or the remote control.



3. Select "Blu-Ray" from the Input buttons on the Control Panel. The projector should detect input from the Blu-ray Player and display content from your screen.
4. Use the Open/Close button to open the tray and load a disc.
5. Once the disc is loaded, the player will read the disc, and you can navigate through the menu and recorded material using the Menu, Selection, and Video Control buttons.
6. To adjust the volume of audio, use the Volume knob on the Control Panel. (See the image above)

Troubleshooting

1. If the Blu-ray Player does not turn on, check to make sure it is plugged in. Also, try using the Power button on the front of the player if you were using the remote.
2. If the TV or projector is not detecting the Blu-ray player input, try pushing the Source or Input button on the remote control for the device.



If you are experiencing issues using this technology during a class, please call the IT Services STAT phone at 610-921-7828.